


BREEZE BANNER STAND




VISUAL

IMAGINE • CREATE • ACTIVATE

INSTRUCTIONS




<1800mm Size>
Width 400~700mm
Length 1800mm



<1600mm Size>
Width 400~700mm
Length 1600mm



1 Please slot pole into the hole of body same as picture.



<For 1600mm>
Please fit top & bottom rods without connector



<For 1800mm>
Please fit top & bottom rods with connector



4 Please attach eyelet of banner to rod ends

***Please use with distinction between top & bottom FRP**
***Please use top FRP to adjust height**

CAUTION

1. Have to fill base with water to add stability for outdoor use(18L)
2. Please have to use standard graphic size
3. Remove while severs storm